1. Female Cable End 2. Dust Cap 3. Lock Nut



a) Using a 5/8" drill bit, make a hole in you equipment in the location that you will be inserting the adaptor cable.

b) Apply a VERY THIN SMEAR of automotive silicone adhesive around the rim of the hole on the side that you are inserting the connector into, making sure to not get any on the threads when the connector is inserted.

c) Insert the female end (1) through the hole; you may need to "wiggle" it a bit, but this ensures a tight fit.

d) REMEMBER, the female connector end (1) is the side that the camera/extension cable to camera will be attaching to.
For cab installation; the cable length will be inside the cab.
For air tank installation; the cable length will be outside the tank.

e) Attach the dust cap (2) and thread lock nut (3).
**Allow 2 hours before use for silicone to set.*